




ref	photo	marque	modèle	ref	photo	marque	modèle
7970		Acos	M7	8149		Audio Technica	ATN51
7971		Acos	GP91	8149 8		Audio Technica	ATN3100
7976		Acos	GP79	8155		AUE	Ondex
8012		ADC	220X	8161		Bang & Olufsen	SP6
8018		ADC	QLM 30 MK	8180		BSR	ST3
8025		ADC	L4	8181		BSR	ST8 & ST10
8030		Astatic	13T	8184		BSR	TC8
8048		Astatic	N52	8186		BSR	ST12, ST15
8070 4		Akai	RS10	8187		BSR	ST16, ST17
8072		Akai	RS90	82006		CEC	N800
8073		Akai	RS100	8260		Clarville	
80782		Akai	RS33	8310		Coner	33
8081		AKG	X6R	8312		Coner	RCS
8089		Amstrad	TS51	8333		Darling	M22
8095		Audio Technica	AT6	83703		Denon	SJN68
8097		Audio Technica	VM35	8422		Dual	DN3
8098		Audio Technica	ATN13	8430		Dual	DN5
8100		Audio Technica	ATN952	8431		Dual	DN6
8101		Audio Technica	AT4	8434		Dual	DN211
8105		Audio Technica	ATS11	8450		Dual	DN145
8108		Audio Technica	ATN12XE	8452		Dual	DN245
8112		Audio Technica	ATN15 & 20	8486		Elac	SNM102
8115		Audio Technica	ATN30	8489		Elac	SNM106
8116		Audio Technica	ATN70	8492		Elac	144
8131		Audio Technica	ATN3400	8540		Empire	66, 2000
9666		Audio Technica	ATN3600	8544		Empire	4000
8134		Audio Technica	ATN120	8554		Empire	S200
8145		Audio Technica	ATN750	8640		Excel	70S

ref	photo	marque	modèle	ref	photo	marque	modèle
8643		Excel	QD700	9263		Pathé Marconi	RC6
8645		Excel	ME45	9264		Pathé Marconi	STC7
88342		Grado	F	9283		Perpetuum Ebner	223
8842		Hitachi	ST15	9314		Philips	GP330
8855		Hitachi	ST40	9317		Philips	N698 3
8910		Kenwood	N39	9323		Philips	AG3016
8912		Kenwood	N47	9326		Philips	AG3063
8925		Kenwood	N39MKIII	9329		Philips	AG3306
8931		Kenwood	N50	9335		Philips	FP772
8936		Kenwood	N54	9336		Philips	GP400
8939		Kenwood	N61	9338		Philips	GP212
8940		Kenwood	N62	9339		Philips	GP204
8961		Lenco	M94	9344		Philips	GP215
8994		Lesa	W	9345		Philips	GP412, GP402 ...
9013		Marantz	221	9350		Philips	GP401 ...
9019 4		Marantz	CT100	9360		Pickering	V15
9020		Marlux	MX56	93605		Pickering	D140 etc
9022		Marlux	YM121	93608		Pickering	DLC
9150		National Panasonic Technics	EPS41 STSD	9402		Piezo	
9165			EPS25	94072		Pioneer	PN290
9167		National Panasonic Technics	EPS270	9410		Pioneer	PN10
9175			EPS50	9411		Pioneer	PN135
91772			EPS202	9413		Pioneer	PN16
9188 2		Nagaoka	N501	9415		Pioneer	PN12
9250		Ortofon	N15, F15 ...	9419		Pioneer	PN200
9255		Ortofon	OM10 etc	9422		Pioneer	PL130
9261		Pathé Marconi	53	9431		Pioneer	PN291
9263o		Pathé Marconi	RC5	9460		Radiohm	6500

ref	photo	marque	modèle	ref	photo	marque	modèle
9462		Radiohm	4pattes	9695		Sony	ND30
9520		Ronette	BF40	9700		Stanton	500
9534		Sansui	SN10	97004		Stanton	681E
9537		Sansui	SN31	9705		Stanton	600A
95393		Sansui	SN37	9782		Telefunken	A10
9540		Sanyo	ST15	9783		Telefunken	200
9541 2		Sanyo	ST66	9784		Telefunken	A23-1
9541 9		Sanyo	ST07	9785		Telefunken	A23, A25
9543 2		Sanyo	ST09	9786		Telefunken	TTSA
9546		Sanyo	ST26	9805		Tenorel	N2001
9547		Sanyo	ST50	9810		Teppaz	MT26
9590		Shure	N92	9812		Teppaz	Eco
9593		Shure	VN45, V15 IV	9813		Teppaz	Stéréo
9596		Shure	SS35C	9814		Teppaz	MT30
9597		Shure	N44-7	9821		Tetrad	72
9600		Shure	N75	9831		Thomson	M307
9605		Shure	N91	9850		Toshiba	N11C
9609		Shure	VN35, V15 III	9853		Toshiba	N3C
9611		Shure	N95	9855		Toshiba	N58C
9616		Shure	N17CM	9856		Toshiba	N280
9619		Shure	N97	9859 9		Toshiba	N62
96202		Seeburg	Stéréo	9865		T.S.	TS1
96203		Seeburg	Showcase	9870		Victor Nivico	DT33H
9665		Sony	ND143G	98702		Victor Nivico	DT55B
9668		Sony	ND150G	9872		Victor Nivico	DTZ1S
9673		Sony	ND133	9895		Victor Nivico	DT37L
9685		Sony	ND15G	99114		VEB	CN24
9686		Sony	ND137G	9912		VEB	KS23

